New Era® Snapback Trucker Cap. NE205

PRODUCT MEASUREMENTS

	OSFA
Crown Height	6 7/8
Bill/Visor Length	2 3/4
Width of Front Panel(s)	7 1/2

CROWN HEIGHT

Measure from middle of button at top, to brim seam along center front.

BILL/VISOR LENGTH

Measure from outside edge of bill to crown seam at center front.

WIDTH OF FRONT PANEL(S)

Measure from side seam to side seam along bottom of crown (where bill meets crown along seam).